

How to manually change the time on an ATM running OS/2

The following procedure will change the time on an ATM running an OS/2 operating system.

- A. Press CTRL and ESC to bring up the window list of applications. Use the arrow keys to highlight 'Toolbar - Palette' and press the Enter key. The 'Toolbar - Palette' will appear as shown below.



- B. On the 'Toolbar – Palette,' use the right arrow key to select the OS/2 Window Icon  (there will be a dotted line around it once selected) and press Enter.
- C. A window will open and there will be a [C:\]. Key in the word TIME (not case sensitive) and press Enter. It will look something like this:
[C:\]TIME
Current time is: 15:57:01.01
Enter the new time:
- D. Key in the new time (in military time) using a colon and press Enter. Example shown below:
[C:\]TIME
Current time is: 15:57:01.01
Enter the new time: 16:57
- Note: If you make a mistake when entering in the time, at the [C:\] key in TIME again and start over. To view the time without a change, key in the word TIME at the [C:\] and when done press Enter. No change will be made.
- E. Once finished, type the word EXIT at the [C:\] and press Enter. The OS/2 Window will close.
- F. Press CTRL and ESC to bring up the window list of applications again. Use the arrow keys to highlight 'TCS' and press Enter. The TCS Window should now re-appear and the Toolbar – Palette should not be seen.